 TheGreenBow IPsec VPN Client
Configuration Guide
Zywall 10

WebSite: <http://www.thegreenbow.com>

Contact: support@thegreenbow.com

Table of contents

1	Introduction	3
1.1	Goal of this document	3
1.2	VPN Network topology	3
1.3	Zyxel Zywall 10 Restrictions.....	3
1.4	Zyxel Zywall 10 VPN Gateway.....	3
1.5	Zyxel Zywall 10 VPN Gateway product info	3
2	Zyxel Zywall 10 VPN configuration	4
3	TheGreenBow IPSec VPN Client configuration	8
3.1	VPN Client Phase 1 (IKE) Configuration.....	8
3.2	VPN Client Phase 2 (IPSec) Configuration	10
3.3	Open IPSec VPN tunnels.....	10
4	Tools in case of trouble.....	12
4.1	A good network analyser: Wireshark	12
5	VPN IPSec Troubleshooting	13
5.1	« PAYLOAD MALFORMED » error (wrong Phase 1 [SA])	13
5.2	« INVALID COOKIE » error.....	13
5.3	« no keystate » error	13
5.4	« received remote ID other than expected » error.....	13
5.5	« NO PROPOSAL CHOSEN » error	14
5.6	« INVALID ID INFORMATION » error	14
5.7	I clicked on “Open tunnel”, but nothing happens.....	14
5.8	The VPN tunnel is up but I can't ping !.....	14
6	Contacts.....	16


1 Introduction

1.1 Goal of this document

This configuration guide describes how to configure TheGreenBow IPsec VPN Client with a Zyxel Zywall 10 VPN router.

1.2 VPN Network topology

In our VPN network example (diagram hereafter), we will connect TheGreenBow IPsec VPN Client to the LAN behind the Zyxel Zywall 10 router. The VPN client is connected to the Internet with a DSL connection or through a LAN. All the addresses in this document are given for example purpose.



1.3 Zyxel Zywall 10 Restrictions

No known restriction.

1.4 Zyxel Zywall 10 VPN Gateway

Our tests and VPN configuration have been conducted with Zyxel Zywall 10 release 3.52.

1.5 Zyxel Zywall 10 VPN Gateway product info


It is critical that users find all necessary information about Zyxel Zywall 10 VPN Gateway. All product info, User Guide and knowledge base for the Zyxel Zywall 10 VPN Gateway can be found on the Zywall 10 website: www.zyxel.com.

- Zywall Product page: <http://us.zyxel.com/products/category.php?indexFlagvalue=1021873683>


2 Zyxel Zywall 10 VPN configuration

This section describes how to build an IPSec VPN configuration with your Zywall 10 VPN router.


Once connected to your Zywall 10 VPN gateway, the home page will show Main Menu.




So first step is to configure the LAN.



Then in the 'WAN' section, you click on 'IP': don't forget to take note of this WAN IP address as it will be used as the remote gateway address in TheGreenBow IPSec VPN Client



Then, go to 'VPN' under menu 'CONTENT FILTER' and select 'Add New Policy'.



Click on 'Edit'.

The screenshot shows the ZyXEL VPN configuration wizard interface. The left sidebar contains navigation options: WIZARD, MAIN MENU, SYSTEM, LAN, WAN, SUA/NAT, STATIC ROUTE, FIREWALL, CONTENT FILTER, VPN, LOGS, MAINTENANCE, and LOGOUT. The main configuration area is yellow and contains the following settings:


- Active Keep alive NAT Traversal
- Name: CnxVpn
- Key Management: IKE
- Negotiation Mode: Main
- Local :
 - Address Type: Subnet Address
 - Starting IP Address: 192.168.1.0
 - Ending IP Address / Subnet Mask: 255.255.255.0
- Remote :
 - Address Type: Single Address
 - Starting IP Address: 0.0.0.0
 - Ending IP Address / Subnet Mask: 0.0.0.0
- Local ID Type: IP
- Content: [Empty]
- My IP Address: 0.0.0.0
- Peer ID Type: IP
- Content: [Empty]
- Secure Gateway Address: 0.0.0.0
- Encapsulation Mode: Tunnel
- ESP AH
 - Encryption Algorithm: 3DES
 - Authentication Algorithm: SHA1
 - Pre-Shared Key: 12345678

Buttons for 'Apply' and 'Cancel' are at the bottom.

So in the part 'Local' you put the Local LAN Address. Select 'NAT Traversal'.

Then, you configure the ESP algorithms with 3DES, SHA and you choose a Preshared Key: 12345678.

Once done, you click on 'Advanced' to configure other parameters required into TheGreenBow IPsec VPN Client.




So here you find again the algorithms for each phase of TheGreenBow IPsec VPN Client. Click on 'Apply' when done.

3 TheGreenBow IPsec VPN Client configuration

This section describes the required configuration to connect to a Zyxel Zywall 10 VPN router.


To download the latest release of TheGreenBow IPsec VPN Client software, please go to http://www.thegreenbow.com/vpn_down.html.

3.1 VPN Client Phase 1 (IKE) Configuration



Phase 1 configuration


As configured in the router, we need to setup the same algorithms for IKE and the same PreShared key.



Don't forget to set 'NAT-T' to 'Automatic'. Click on 'Ok'.

Now, you've completed configuration of the Phase 1.

3.2 VPN Client Phase 2 (IPSec) Configuration



Phase 2 Configuration


The part ESP shall match the Phase2 group in the Zywall VPN router.

3.3 Open IPSec VPN tunnels

Once both Zyxel Zywall 10 router and TheGreenBow IPSec VPN Client software have been configured accordingly, you are ready to open VPN tunnels. First make sure you enable your firewall with IPSec traffic.

1. Click on "Save & Apply" to take into account all modifications we've made on your VPN Client configuration
2. Click on "Open Tunnel", or generate traffic that will automatically open a secure IPSec VPN Tunnel (e.g. ping, IE browser)
3. Select "Connections" to see opened VPN Tunnels

4. Select "Console" if you want to access to the IPSec VPN logs and adjust filters to display less IPSec messaging. The following example shows a successful connection between TheGreenBow IPSec VPN Client and a Zyxel Zywall 10 VPN router.



```

tgbvpn20080331_095324.log - Bloc-notes
-----
Fichier  Edition  Format  Affichage  ?
20080331 095259 Default IKE daemon is removing SAs...
20080331 095305 Default Reinitializing IKE daemon
20080331 095305 Default IKE daemon reinitialized
20080331 095308 Default (SA CnxVpnl-P1) SEND phase 1 Main Mode [SA] [VID] [VID] [VID] [VID] [VID]
20080331 095312 Default (SA CnxVpnl-P1) RECV phase 1 Main Mode [SA] [VID] [VID]
20080331 095312 Default (SA CnxVpnl-P1) SEND phase 1 Main Mode [KEY_EXCH] [NONCE] [NAT_D] [NAT_D]
20080331 095315 Default (SA CnxVpnl-P1) RECV phase 1 Main Mode [KEY_EXCH] [NONCE] [NAT_D] [NAT_D]
20080331 095315 Default (SA CnxVpnl-P1) SEND phase 1 Main Mode [HASH] [ID]
20080331 095315 Default (SA CnxVpnl-P1) RECV phase 1 Main Mode [HASH] [ID] [NOTIFY]
20080331 095315 Default phase 1 done: initiator id 10.0.0.5, responder id 10.0.0.1
20080331 095316 Default (SA CnxVpnl-Zywall-P2) SEND phase 2 Quick Mode [HASH] [SA] [KEY_EXCH] [NONCE] [ID] [ID]
20080331 095323 Default (SA CnxVpnl-Zywall-P2) SEND phase 2 Quick Mode [HASH] [SA] [KEY_EXCH] [NONCE] [ID] [ID]
20080331 095323 Default (SA CnxVpnl-Zywall-P2) RECV phase 2 Quick Mode [HASH] [SA] [KEY_EXCH] [NONCE] [ID] [ID] [NOTIFY]
20080331 095323 Default (SA CnxVpnl-Zywall-P2) SEND phase 2 Quick Mode [HASH]
  
```

4 Tools in case of trouble

Configuring an IPSec VPN tunnel can be a hard task. One missing parameter can prevent a VPN connection from being established. Some tools are available to find source of troubles during a VPN establishment.

4.1 A good network analyser: Wireshark

Wireshark is a free software that can be used for packet and traffic analysis. It shows IP or TCP packets received on a network card. This tool is available on website <http://www.wireshark.org>. It can be used to follow protocol exchange between two devices. For installation and use details, read its specific documentation (<http://www.wireshark.org/docs/>).

5 VPN IPSec Troubleshooting

5.1 « PAYLOAD MALFORMED » error (wrong Phase 1 [SA])

```
114920 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [SA][VID]
114920 Default (SA CNXVPN1-P1) RECV phase 1 Main Mode [NOTIFY]
114920 Default exchange_run: exchange_validate failed
114920 Default dropped message from 195.100.205.114 port 500 due to notification
type PAYLOAD_MALFORMED
114920 Default SEND Informational [NOTIFY] with PAYLOAD_MALFORMED error
```

If you have an « PAYLOAD MALFORMED » error you might have a wrong Phase 1 [SA], check if the encryption algorithms are the same on each side of the VPN tunnel.

5.2 « INVALID COOKIE » error

```
115933 Default message_rcv: invalid cookie(s) 5918ca0c2634288f 7364e3e486e49105
115933 Default dropped message from 195.100.205.114 port 500 due to notification
type INVALID_COOKIE
115933 Default SEND Informational [NOTIFY] with INVALID_COOKIE error
```

If you have an « INVALID COOKIE » error, it means that one of the endpoint is using a SA that is no more in use. Reset the VPN connection on each side.

5.3 « no keystate » error

```
115315 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [SA][VID]
115317 Default (SA CNXVPN1-P1) RECV phase 1 Main Mode [SA][VID]
115317 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [KEY][NONCE]
115319 Default (SA CNXVPN1-P1) RECV phase 1 Main Mode [KEY][NONCE]
115319 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [ID][HASH][NOTIFY]
115319 Default ipsec_get_keystate: no keystate in ISAKMP SA 00B57C50
```

Check if the preshared key is correct or if the local ID is correct (see « Advanced » button). You should have more information in the remote endpoint logs.

5.4 « received remote ID other than expected » error

```
120348 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [SA][VID]
120349 Default (SA CNXVPN1-P1) RECV phase 1 Main Mode [SA][VID]
120349 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [KEY][NONCE]
120351 Default (SA CNXVPN1-P1) RECV phase 1 Main Mode [KEY][NONCE]
120351 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [ID][HASH][NOTIFY]
120351 Default (SA CNXVPN1-P1) RECV phase 1 Main Mode [ID][HASH][NOTIFY]
120351 Default ike_phase_1_rcv_ID: received remote ID other than expected
support@thegreenbow.fr
```

The « Remote ID » value (see « Advanced » Button) does not match what the remote endpoint is expected.

5.5 « NO PROPOSAL CHOSEN » error

```

115911 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [SA][VID]
115913 Default (SA CNXVPN1-P1) RECV phase 1 Main Mode [SA][VID]
115913 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [KEY][NONCE]
115915 Default (SA CNXVPN1-P1) RECV phase 1 Main Mode [KEY][NONCE]
115915 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [ID][HASH][NOTIFY]
115915 Default (SA CNXVPN1-P1) RECV phase 1 Main Mode [ID][HASH][NOTIFY]
115915 Default phase 1 done: initiator id c364cd70: 195.100.205.112, responder id
c364cd72: 195.100.205.114, src: 195.100.205.112 dst: 195.100.205.114
115915 Default (SA CNXVPN1-CNXVPN1-P2) SEND phase 2 Quick Mode
[SA][KEY][ID][HASH][NONCE]
115915 Default RECV Informational [HASH][NOTIFY] with NO_PROPOSAL_CHOSEN error
115915 Default RECV Informational [HASH][DEL]
115915 Default CNXVPN1-P1 deleted

```

If you have an « NO PROPOSAL CHOSEN » error, check that the « Phase 2 » encryption algorithms are the same on each side of the VPN Tunnel.

Check « Phase 1 » algorithms if you have this:

```

115911 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [SA][VID]
115911 Default RECV Informational [NOTIFY] with NO_PROPOSAL_CHOSEN error

```

5.6 « INVALID ID INFORMATION » error

```

122623 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [SA][VID]
122625 Default (SA CNXVPN1-P1) RECV phase 1 Main Mode [SA][VID]
122625 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [KEY][NONCE]
122626 Default (SA CNXVPN1-P1) RECV phase 1 Main Mode [KEY][NONCE]
122626 Default (SA CNXVPN1-P1) SEND phase 1 Main Mode [ID][HASH][NOTIFY]
122626 Default (SA CNXVPN1-P1) RECV phase 1 Main Mode [ID][HASH][NOTIFY]
122626 Default phase 1 done: initiator id c364cd70: 195.100.205.112, responder id
c364cd72: 195.100.205.114, src: 195.100.205.112 dst: 195.100.205.114
122626 Default (SA CNXVPN1-CNXVPN1-P2) SEND phase 2 Quick Mode
[SA][KEY][ID][HASH][NONCE]
122626 Default RECV Informational [HASH][NOTIFY] with INVALID_ID_INFORMATION error
122626 Default RECV Informational [HASH][DEL]
122626 Default CNXVPN1-P1 deleted

```

If you have an « INVALID ID INFORMATION » error, check if « Phase 2 » ID (local address and network address) is correct and match what is expected by the remote endpoint.

Check also ID type ("Subnet address" and "Single address"). If network mask is not check, you are using a IPV4_ADDR type (and not a IPV4_SUBNET type).

5.7 I clicked on "Open tunnel", but nothing happens.

Read logs of each VPN tunnel endpoint. IKE requests can be dropped by firewalls. An IPSec Client uses UDP port 500 and protocol ESP (protocol 50).

5.8 The VPN tunnel is up but I can't ping !

If the VPN tunnel is up, but you still cannot ping the remote LAN, here are a few guidelines:

- Check Phase 2 settings: VPN Client address and Remote LAN address. Usually, VPN Client IP address should not belong to the remote LAN subnet
- Once VPN tunnel is up, packets are sent with ESP protocol. This protocol can be blocked by firewall. Check that every device between the client and the VPN server does accept ESP
- Check your VPN server logs. Packets can be dropped by one of its firewall rules.
- Check your ISP support ESP

Doc.Ref	tgbvpn_ug_Zywall10_en
Doc.version	3.0 – Apr 2008
VPN version	4.x

- If you still cannot ping, follow ICMP traffic on VPN server LAN interface and on LAN computer interface (with Wireshark for example). You will have an indication that encryption works.
- Check the “default gateway” value in VPN Server LAN. A target on your remote LAN can receive pings but does not answer because there is a no “Default gateway” setting.
- You cannot access to the computers in the LAN by their name. You must specify their IP address inside the LAN.
- We recommend you to install Wireshark (<http://www.wireshark.org>) on one of your target computer. You can check that your pings arrive inside the LAN.

	Doc.Ref	tgbvpn_ug_Zywall10_en
	Doc.version	3.0 – Apr 2008
	VPN version	4.x

6 Contacts

News and updates on TheGreenBow web site: <http://www.thegreenbow.com>

Technical support by email at support@thegreenbow.com

Sales contacts by email at sales@thegreenbow.com